# **Experiment 9**


## **Shift Register**


## **Outline**

In this experiment, it is expected from you to,

- 1. Learn the shift register structure and usage
- 2. Assemble and test the shift register circuit
- 3. Modification


#### 1. Shift Register





**Structure of Shift Register** 

A shift register is a type of digital circuit using a cascade of flip-flops where the output of one flip-flop is connected to the input of the next. They share a single clock signal, which causes the data stored in the system to shift from one location to the next. By connecting the last flip-flop back to the first, the data can cycle within the shifters for extended periods, and in this form they were used as a form of computer memory.




**Logic Diagram of the Shift Register** 

### 2. Assembling the Shift Register Circuit



**Required Parts** 



Fritzing Diagram of the Circuit

- 1. Select your resistors (330  $\Omega$ ) by using the color code table
- 2. Connect your shift register and the LEDs as shown in the diagram
- 3. Verify and upload your code to the arduino board
- 4. Observe the result and compare it with the expected outcome

**Expected Outcome:** LEDs should turn on one after another then they should turn off in reverse order.

# **Modification**

Use a shift register, 8 LEDs and the serial port as follows,

- 1. Serial port will be used to read the input
  - o Input will be in type of integer value
  - Range of input is [0 255]
- 2. By using LEDs visualize the binary equivalent of the input value.
  - Turned on state means 1
  - Turned off state means 0